User Manual

Notes: Please use authorized high speed Micro SD card (C10 or above).

Usage Instructions

1. Playback
2. Delete
3. Print
4. Display Power Button
5. Display
6. Timer (Left Button)
7. Focus (Macro)
   (Up Button)
8. Frame Selector
   (Right Button)
9. WIFI/Color Effect Selector
   (Down Button)
10. Shutter(OK Button)
11. Photo/VideoSwitch
12. Home(Menu Button)
13. Paper Roll
    Compartment
14. Flash
15. Selfie Mirror
16. Paper Roll
    Compartment
    Release Lever
17. Lens
18. Tripod Mount Socket
19. Power Switch
20. USB Port
21. microSD Card Cover

1. Installing and changing the microSD™ Card

- It is generally recommended to use a new microSD card or one that has been formatted prior to use. This helps improve compatibility with the camera.
- To format a microSD card, go to the Home screen and select Settings. Choose Format and select Yes. An alert "PLEASE WAIT" will appear on the screen during formatting and disappear when formatting is completed.

Please note

Formatting will delete all pictures stored on the microSD card. If you do not want to delete pictures, please either download them to your computer or use a fresh card.

Installing and changing the Paper Roll



- Gently press the Paper Roll Compartment Release Lever.
- Unspool the end of the roll slightly.
- Install the Paper Roll as shown (A), with the loose end closest to the Lens. Allow a small amount of the paper to stick out so that it will feed into the system properly.
- Replace Paper Roll Compartment lid until it clicks into place (B)

Charging your camera

- Open the USB Port/microSD Card Cover.
- Connect a Mini USB Cable to the camera, then to a 5V 1A-2A wall charger.
- The Indicator Light will illuminate red during charging, and shut off once fully charged.

- Turn Power Switch on.
- Press and hold the Display Power Button. Indicator light will turn blue.
- Press and hold the Display Power Button again. Indicator light will turn off.

Introduction of Buttons and Functions

Buttons and functions



1. HOME (Menu Button)

Press HOME to enter Main Menu. Press Left or Right Buttons to choose settings. Press Up or Down Buttons to view options in different settings, and press the OK Button to select.

2. Photo/Video Switch

Press the button to switch back and forth between photo and video. Photo mode is the default. In either mode, press OK Button to capture the image or video.

3. WIFI/Color Effects Selector (Down Button)



Choose between color effects by using the Down buttons. Press the OK button to capture photo or video with your selected color effects.

WIFI Function introduction

1. Acquiring APP and installation (support Android and IOS system). There is a 2 seconds' delay of image in App.

①Scan QR code accordingly to get App and install in your cellphone or tablet.

② For Android system, search "Hi Cam+" in "Google Play" or "Baidu" to get the App and install.

③ For IOS system, Seach "Hi Cam+" in "App Store" to get the App and install.

2. Press and hold the WIFI button to switch on WiFi, there will be WiFi info displaying on screen. (Effective WiFi distance is 3 meters)

3. Go to WLAN in cellphone/tablet, find corresponding WiFi name and input password to connect.

4. Open up "Hi Cam+" App in cellphone/tablet and connect camera, the image of camera will be shown in App. Photo taking, video shooting, downloading etc can be done through the App. (Notes: video shooted is usable to be played in the App. Please download video to cellphone first, then play)

4. Frame Selector (Right Button)

Choose between photo frame options by using the Left Button or Right Button. Press OK Button to capture photo with selected frame. In Video Mode, press right button to turn on flash.

5. Focus (Macro) Button (Up Button)

Choose between Macro (Close-Up) and Distance modes (please ensure the camera is in Distance mode when your subject is far away to avoid a blurry image).

6. Timer (Left Button)

With camera in Photo Mode, press Timer to set the timer for 10 seconds. Then press OK Button to start the countdown.

7. Playback

Press Playback, then the Left or Right Buttons to review Photo or Video.

8. Delete

During Photo/Video playback, press Left or Right Buttons to review Photo or Video.Press Delete Button to enter the Delete Menu. Use the Up or Down buttons to choose Yes or No. Press OK Button to delete.

9. Print

Press Print to turn the instant print function on. A printer icon will appear in the bar at the top of the display. This enables photos to be printed out instantly as well as being stored on the microSD Card. If you press Print again, the function will switch to Off, andphotos will simply be stored on the microSD Card. When in playback, press print button enables you to print photo out as well.

Please note: Turn instant print function off without microSD card. only 1 photo can be stored. Turn instant print function on without microSD card, photos could be printed out instantly, while could not be stored.

Technical Parameters

Size of the product	96*128*89MM
Focusing range	50CM- INFINITE MICRO 10CM
Battery Life	PHOTO PRINT: ~1110PCS VIDEO: ~1.5H
Printing Paper Specification	W57* 2 30(MM)
File Format	JPG, AVI
Timing Shoot	OFF,10SECON
Flash	LED OFF、AUTO、ON
Auto power off	AUTO 3MIN
PC Interface	USB2.0
Size of the monitor	TFT 2.4INCH IPS 320*240
Battery Type	LI-BATTERY 7.4V 1100MAH
Language	Multi-language(Chinese ,English, Francais,German, Espanol,Italiano,Japanese、Russian)
Charger	DC 5V 2A